



FSWP1820

Pull-out Mount for Flat Panel Monitors

1. Remove trim around armoire screen opening.
2. Attach the flat screen wall plate to the wall with four (4) #14x2 1/2 tapping screws, with driver extender.
3. Attach the adaptor plate to back of flat screen with four (4) M5x16mm .8 panhead and #10 flat washers provided.
4. Lift flat screen (two workers required) to the pullout interface. Tilt the screen so that the flange of adaptor hooks over the upper edge of the pullout interface. The four studs on the adaptor plate pass through holes on the interface.
5. Release the latch on the pullout interface by lifting the latch tabs at bottom corners and pull out the interface.
6. Secure the screen with the provided 1/4" fender washers and 1/4-20 nylon nuts to the studs on the adaptor plate. Use a 7/16" socket wrench.
7. Install cables and other equipment according to manufacturer's instructions.
8. Secure the unit by pressing television frame back to the wall. *Do not push on the glass screen itself.*
If latch seems loose, press down on the tabs.
9. Replace the trim removed in step 1.